

Manufacturer	Model	Port to Port Length	Flange Size	Grundfos Model	Port to Port Length	Flange Size
B&G	2-1/2"	10"	2-1/2"	UP53-45F ¹	9-7/8"	2"-2.5-3"
	LD3	10"	3"	UP53-45F ¹	9-7/8"	2"-2.5-3"
	HD3	10"	3"	UP53-46F ¹	9-7/8"	2"-2.5-3"
	PD-35	12"	3"	UPS53-55/57F ¹	11-7/8"	2"-2.5-3"
	PD-37	12"	3"	UPS53-55/57F ¹	11-7/8"	2"-2.5-3"
	PD-38	14-1/2"	3"	UPS75-69F ¹	14"	2"-2.5-3"
	PD-40	14-1/2"	3"	UPS50-160/2 ^{1,2}	14"	2"
	601	11"	1"	UPS32-80/2 ¹	11"	3/4" to 1-1/2"
	602	11"	1"	UPS32-80/2 ¹	11"	3/4" to 1-1/2"
	603	11"	1"	UPS50-80/2 ^{1,2}	11-1/2"	2"
	604	11"	1-1/4"	UPS32-80/2 ¹	11"	3/4" to 1-1/2"
	609	11-1/2"	1-1/2"	UPS40-160/2 ¹	11-1/2"	1-1/2"
	610	11-1/2"	2"	UPS50-80/4 ¹	11-1/2"	2"
	621	13-1/2"	2"	UPS40-80/4	13-1/2"	1-1/2"
	614	13-1/2"	1-1/2"	UPS40-240/2	13-1/2"	1-1/2"
	615	13-1/2"	2"	UPS50-160/2	14"	2"
	616	13-1/2"	2"	UPS50-160/2	14"	2"
	622	13-1/2"	1-1/2"	UPS32-160/2	13-1/2"	1-1/2"
	623	13-1/2"	1-1/2"	UPS40-240/2	13-1/2"	1-1/2"
	617	13-1/2"	1-1/2"	UPS40-240/2	13-1/2"	1-1/2"
	624	14"	2"	UPS50-160/2	14"	2"
	625	14"	2"	UPS50-240/2	14"	2"
	60-11	11"	1-1/4"	UPS32-80/2 ¹	11"	3/4" to 1-1/2"
	60-13	11-1/2"	1-1/2"	UPS40-160/2 ¹	11-1/2"	1-1/2"
	60-14	11-1/2"	2"	UPS50-80/2 ¹	11-1/2"	2"
	60-15	13-1/2"	1-1/2"	UPS32-160/2	13-1/2"	3/4" to 1-1/2"
60-16	13-1/2"	1-1/2"	UPS32-160/2	13-1/2"	3/4" to 1-1/2"	
60-17	13-1/2"	1-1/2"	UPS40-240/2	13-1/2"	1-1/2"	
60-19	14"	2"	UPS50-160/2	14"	2"	
60-20	14"	2"	UPS50-160/2	14"	2"	
60-21	14"	2"	UPS50-240/2	14"	2"	
TACO	120	11"	2"	UPS32-40/4 ^{1,2}	11"	3/4" to 1-1/2"
	131	13-5/8"	3"	UP53-45F ^{1,2}	10"	2"
	133	13-5/8"	3"	UPS53-55/57 ^{1,2}	11-7/8"	3"
	1600	10-1/4"	1-1/2"	UPS32-80/2 ¹	11"	1-1/2"
	1610	10-1/4"	1-1/2"	UPS32-80/2 ¹	11"	1-1/2"
	1612	13-1/2"	1-1/2"	UPS32-160/2 ¹	13-1/2"	1-1/2"
	1614	13-1/2"	1-1/2"	UPS32-160/2 ¹	13-1/2"	1-1/2"
	1616	14-1/2"	2"	UPS40-240/2 ^{1,2}	13-1/2"	1-1/2"
	1630	13-1/2"	2"	UPS50-80/4 ^{1,2}	11-1/2"	2"
	1632	13-1/2"	2"	UPS50-160/2 ¹	14"	2"
	1634	13-1/2"	2"	UPS50-160/2 ¹	14"	2"
	1636	16-1/2"	2"	UPS50-240/2 ^{1,2}	14"	2"
	1638	16-1/2"	2"	UPS50-240/2 ^{1,2}	14"	2"

PUMP CROSS REFERENCE GUIDE

Manufacturer	Model	Port to Port Length	Flange Size	Grundfos Model	Port to Port Length	Flange Size
ARMSTRONG	ARMflo E21	8-1/2"	1-1/2"	UP43-110F	8-1/2"	1-1/2"
	ARMflo E23	8-1/2"	1-1/2"	UP43-110F	8-1/2"	1-1/2"
	S 45	10"	2-1/2" - 3"	UP53-45F ¹	9-7/8"	2" - 2-1/2" - 3"
	S 46	10"	2-1/2" - 3"	UP53-46F ¹	9-7/8"	2" - 2-1/2" - 3"
	S 55	12"	3"	UPS53-55/57F ¹	11-7/8"	2" - 2-1/2" - 3"
	S 57	12"	3"	UPS53-55/57F ¹	11-7/8"	2" - 2-1/2" - 3"
	S 69	14-1/4"	3"	UPS75-69F ¹	14"	2" - 2-1/2" - 3"
	H51	11-1/2"	1"	UPS32-80/2 ^{1,2}	11"	2" - 2-1/2" - 3"
	H52	11-1/2"	1"	UPS32-80/2 ^{1,2}	11"	3/4" to 1-1/2"
	H53	11-1/2"	1-1/2"	UPS40-160/2 ¹	11-1/2"	1-1/2"
	H54	11-1/2"	2"	UPS50-80/2 ¹	11-1/2"	2-1/2"
	H63	13-1/2"	1-1/2"	UPS32-160/2 ¹	13-1/2"	1-1/2"
	H64	13-1/2"	1-1/2"	UPS32-160/2 ¹	13-1/2"	1-1/2"
	H65	13-1/2"	1-1/2"	UPS40-240/2 ¹	13-1/2"	1-1/2"
	H66	14"	2"	UPS50-160/2 ¹	14"	2"
	H67	14"	2"	UPS50-160/2 ¹	14"	2"
	H68	14"	2"	UPS50-240/2 ¹	14"	2"
	1050 1B (1/4 HP)	11-1/2"	1"	UPS32-80/2 ^{1,2}	11"	3/4" to 1-1/2"
	1050 1-1/4B (1/4 HP)	11-1/2"	1-1/4"	UPS32-80/2 ^{1,2}	11"	3/4" to 1-1/2"
	1050 1-1/2B (1/4 HP)	11-1/2"	1-1/2"	UPS32-80/2 ^{1,2}	11"	3/4" to 1-1/2"
	1050 2B (1/3 HP)	11-1/2"	2"	UPS50-80/4 ¹	11-1/2"	2"
	1050 2B (1/2 HP)	11-1/2"	2"	UPS50-80/4 ¹	11-1/2"	2"
	1050 2B (3/4 HP)	11-1/2"	2"	UPS50-80/4 ¹	11-1/2"	2"
	1060 1-1/2D (1/2 HP)	13-1/2"	1-1/2"	UPS32-160/2 ¹	13-1/2"	1-1/2"
	1060 1-1/2D (3/4 HP)	13-1/2"	1-1/2"	UPS32-160/2 ¹	13-1/2"	1-1/2"
	1060 1-1/2D (1-1/2 HP)	13-1/2"	1-1/2"	UPS40-240/2 ¹	13-1/2"	1-1/2"
	1060 2D (3/4 HP)	14"	2"	UPS50-160/2 ¹	14"	2"
	1060 2D (1 HP)	14"	2"	UPS50-160/2 ¹	14"	2"
	1060 2D (1-1/2 HP)	14"	2"	UPS50-160/2 ¹	14"	2"
	1060 2D (2 HP)	14"	2"	UPS50-240/2 ¹	14"	2"

¹Bronze version to be used in open systems.

²Replacement model requires piping and/or flange modification.

INCORRECT



Are you sure your pump's electrical connections are correct?

With Grundfos' VersaFlo® UPS, the red indicator light on the terminal box tells you the pump is rotating incorrectly.

CORRECT

